



Assembly Instructions

1 insert the seat post into the frame (1), then tighten the binder bolt (2) to secure it * 70in-lbs (8Nm)



2 attach the handlebars to the top of the stem, then evenly tighten the two faceplate bolts *210 in-lbs (24 Nm)



3 insert the stem into the scooter's head tube, then *partially* tighten the wedge bolt



4 fold the stem up, then close the hinge quick release¹



5 align the handlebars to be perpendicular to the front wheel, then repeat step 3, fully tightening the wedge bolt *250in-lbs (28.5 Nm)



6 charge the battery (8 hours initially, then 6-8 hours after each ride). check brake for proper operation before riding



*see owner's manual for more detailed information on all topics
¹refer to owner's manual for proper quick release adjustment